



- | 10-5400 | 1/2 Up - 3/8 Down FBSS Kit |
|---------------------------------------|----------------------------|
| (4) U = 3/8 npt to 1/2 line straight | |
| (2) T = 1/2 npt to 1/2 line straight | |
| (2) V = 1/2 npt to 1/2 line elbow | |
| (4) S = 1/2 M to 1/2 M npt | |
| (1) R = 1/8 F to 3/8 M npt | |
| (4) E = 1/2 M to 3/8 F npt | |
| (3) G = 3/8 M to 1/4 F npt | |
| (4) N = 1/2 M to 1/2 F npt Swivel | |
| (4) H = 3/8 M - 3/8 M - 3/8 F npt tee | |
| (1) P = 3/8 npt Plug | |
| (4) M = 3/8 npt muffer (optional) | |
| (1) L = Pressure switch | |
- Air Line
- Cool Cars**
 7514 Preston Hwy. Louisville, KY 40219
 (502) 969-7600 - coolcars7514@aol.com