



11-5200 3/8 Up - 3/8 Down FBSS Kit

- L = (1) Pressure switch
- J = (4) 3/8 npt to 3/8 line straight
- K = (2) 1/2 npt to 3/8 line straight
- B = (2) 1/2 npt to 3/8 line elbow
- Q = (4) 1/2 M to 3/8 M npt
- R = (1) 1/8 F to 3/8 M npt
- G = (2) 3/8 M to 1/4 F npt
- N = (4) 1/2 M to 1/2 F npt Swivel
- H = (4) 3/8 M - 3/8 M - 3/8 F npt tee
- P = (2) 3/8 npt Plug
- M = (4) 3/8 npt muffler (optional)

--- Air Line

Cool Cars
 7514 Preston Hwy. Louisville, KY 40219
 (502) 969-7600 - coolcars7514@aol.com