



11-5338 3/8 FBSS Fast Bag Kit

- (8) J = 3/8 npt to 3/8 line straight
- (2) K = 1/2 npt to 3/8 line straight
- (2) B = 1/2 npt to 3/8 line elbow
- (3) I = 3/8 F - 3/8 F - 3/8 M npt tee
- (1) R = 1/8 F to 3/8 M npt
- (2) F = 3/8 M to 3/8 M npt
- (3) G = 3/8 M to 1/4 F npt
- (7) H = 3/8 M - 3/8 M - 3/8 F npt tee
- (4) M = 3/8 npt muffler (optional)

----- Air Line

COOL Cars
 7514 Preston Hwy. Louisville, KY 40219
 (502) 969-7600 - coolcars7514@aol.com