



### Single Dump Assembly (Fuerte)

- (1) F1 = 1" M to 1" M Elbow
- (1) A = Parker 1" female checkvalve
- (1) O = 1" M #16 #16 Tee
- (1) P = #16 F jic to #12 M jic
- (1) X = #16 F jic to #8 M jic
- (1) G1 = 3/8 M to #8 Swivel
- (1) Y = 1/4 M to 3/8 M
- (1) V = 1/4 M to #6 straight
- (1) D1 = 3/8 M to #6 elbow
- (2) M = 3/8 plug

# Cool Cars

7514 Preston Hwy. Louisville, KY 40219  
 (502) 969-7600 - coolcars7514@aol.com  
 web: www.coolcars.org